

INSTALLATION INSTRUCTIONS

Toyota/Lexus/Scion ASWC-1 harness

LEXUS		RX 350	2007-2010	Highlander*	2004-up
ES 330	2005-2006	RX400H	2006-2008	Land Cruiser	2003-2007
ES 350	2007-2009			Land Cruiser (non-NAV)	
GS 300/350/430/430h/460		SCION			2008-2013
	2006-2008	iQ	2012-2013	Matrix* (standard audio)	
GS 350/450h/460	2009	tC	2006-2013		2009-2013
GX Series	2003-2009	xA	2006	Prius	2004-2009
HS 250h	2010	xB	2006-2012	RAV4	2004-2011
IS 250/250C/350/350C/ISF		xD	2008-2013	Sequoia*	2003-up
	2006-2010	TOYOTA		Sienna	2004-up
LS 460/600h	2007-2009	4Runner*	2003-up	Solara	2004-2008
LX 470	2003-2009	Avalon	2005-2012	Tacoma	2005-2012
LX 570	2008-2009	Camry	2005-2011	Tundra	2003-2013
RX Series	2004-2009	Corolla (all trims)	2009-2012	Venza	2009-2012
RX 330	2004-2006	FJ Cruiser*	2007-up	Yaris (sedan)	2012

*Note, these models, the OE steering wheel harness must be 20-pin. Models needing a 28-pin harness must use the AX-TOY28SWC. This applies to the 2013-up models only.

When installing an aftermarket radio, the 70-8114 will allow the user to retain their factory installed steering wheel controls without having to splice into the factory wiring (ASWC-1 required and sold separately). In addition, we include RCA's to allow the user to retain their factory installed 3.5mm AUX IN jack (aftermarket radio must have a audio AUX IN).

INSTALLATION:

1. Connect the **Red** wire to 12-volt accessory power.
2. Connect the **Black** wire to chassis ground (by itself).
3. Connect the 3.5mm jack to the steering wheel control input, in the aftermarket radio.
4. Connect the **White** RCA jack to the left audio AUX IN of the aftermarket radio (if equipped).
5. Connect the **Red** RCA to the right audio AUX IN of the aftermarket radio (if equipped).

NOTE:

1. Audio devices connected through the 3.5mm jack will be controlled from the audio device, not the aftermarket radio.
2. Please refer to the ASWC-1 programming instructions for programming of the ASWC-1.

INSTRUCCIONES DE INSTALACIÓN

Arnés ASWC-1 Toyota/Lexus/Scion

LEXUS		RX 350	2007-2010	Highlander*	2004 y mas
ES 330	2005-2006	RX400H	2006-2008	Land Cruiser	2003-2007
ES 350	2007-2009			Land Cruiser (sin NAV)	
GS 300/350/430/430h/460		SCION			2008-2013
	2006-2008	iQ	2012-2013	Matrix* (audio estándar)	
GS 350/450h/460	2009	tC	2006-2013		2009-2013
GX Series 2003-2009		xA	2006	Prius	2004-2009
HS 250h	2010	xB	2006-2012	RAV4	2004-2011
IS 250/250C/350/350C/ISF		xD	2008-2013	Sequoia*	2003 y mas
	2006-2010	TOYOTA		Sienna	2004 y mas
LS 460/600h	2007-2009	4Runner*	2003 y mas	Solara	2004-2008
LX 470	2003-2009	Avalon	2005-2012	Tacoma	2005-2012
LX 570	2008-2009	Camry	2005-2011	Tundra	2003-2013
RX Series 2004-2009		Corolla (todo trims)	2009-2012	Venza	2009-2012
RX 330	2004-2006	FJ Cruiser*	2007 y mas	Yaris (sedán)	2012

*Nota, estos modelos, el arnés volante OE debe ser de 20-pin. Modelos que requieren un arnés de 28 pines deben utilizar el AX-TOY28SWC. Esto se aplica sólo a los modelos 2013 y mas.

Al instalar un radio de posventa, el 70-8114 permitirá al usuario retener sus controles del volante instalados de fábrica sin tener que realizar un empalme al cableado de fábrica (requerido por el ASWC-1 y vendido por separado). Además, incluimos los conectores RCA para permitir que el usuario retenga su enchufe de 3.5 mm instalado de fábrica (el radio de posventa debe tener una entrada auxiliar).

INSTALLATION:

1. Conecte el cable **Rojo** de alimentación auxiliar de 12-voltios.
2. Conecte el cable **Negro** a tierra del chasis (por sí mismo).
3. Conecte el jack de 3.5 mm para la entrada de control del volante, en la radio no original.
4. Conecte el conector RCA **blanco** a la izquierda de audio AUX IN de la radio no original (si está instalado).
5. Conecte el RCA **Rojo** a la derecha de audio AUX IN de la radio no original (si está instalado).

NOTE:

1. Audio devices connected through the 3.5mm jack will be controlled from the audio device, not the aftermarket radio.
2. Please refer to the ASWC-1 programming instructions for programming of the ASWC-1.