BACKUPCAM-3 GM Trucks / SUV's 2014-up

INTRODUCTION

The BACKUPCAM-3 is designed to retain the factory backup camera in all but Base model vehicles, so it can be viewed through the display screen on the aftermarket radio.

INTERFACE COMPONENTS

12-pin harness with a yellow RCA jack


APPLICATIONS

Colorado	2015-up
Silverado1500	2014-up
Silverado 2500/3500	2015-up
Suburban	2015-up
Tahoe	2015-up
GMC	
UNIC	
Canyon	2015-up
Canyon Sierra 1500	2015-up 2014-up
Canyon	
Canyon Sierra 1500	2014-up

Note: This interface will not work in Base model vehicles with a 103 radio.

1-800-221-0932

CHEVROLET



© COPYRIGHT 2004-2015 METRA FLECTRONICS CORPORATION

Installation Instructions for INSTBACKUPCAM-3



Connections to be made


From the 12-pin harness with a Yellow RCA jack

To the aftermarket radio:

. Connect the Yellow RCA jack to the BACKUP CAMERA input.

To the vehicle:

. Connect the female 12-pin harness with a Yellow RCA jack, to the male Gray harness removed from the Human Machine Interface module. (Figure A)



(Arrow points to the location)

For the Chevy Colorado and GMC Canyon:

• This module is located in the radio cavity, down low.

For all other models:

- This module is located behind the glove box. There are (2) modules behind the glove box. This module is behind the metal dashboard support. (Figure B)
- Drop the glove box down by first removing the retaining cable on the right side. Then squeeze the glove box sides and gently pull down.
- Remove (6) T-15 Torx screws securing the plastic panel now exposed.



KNOWLEDGE IS POWER Enhance your installation and fabrication skills tenrolling in the most recognized and respected mobile electronics school in our industry. Log onto www.installerinstitute.com or call 800-354-6782 for more information and take steps




Metra recommends MECP certified technicians

Caution: Metra recommends disconnecting the negative battery terminal before beginning any installation. All accessories, switches, and especially air bag indicator lights must be plugged in before reconnecting the battery or cycling the ignition.

Note: Refer to the instructions included with the aftermarket radio.

1-800-221-0932



(Figure B)